# Hydraulic Oil, Manifolds and Fittings



▼ Shown: A-65, FZ-1625, HF-95Y, FZ-1634, FZ-1607, A-64, AM-21



- Maximum pump volumetric efficiency
- Maximum internal heat transfer
- · Prevents pump cavitation
- Additives prevent rust, oxidation and sludge
- High viscosity index
- Maximum film protective lubricity

### The Genuine Range

### **Hydraulic Oil**

Contents	Model Number	Use only genuine Enerpac Hydraulic Oil.			
1 litre	HF-95X	The use of any other fluid will render your			
5 litres	HF-95Y	Enerpac warranty null			
60 litres	HF-95Z	and void.			

#### **▼** Oil Specifications chart

Viscosity Index	100 min
Viscosity at 210°F	42/45 S.U.S.
Viscosity at 100°F	150/165 S.U.S.
Viscosity at 0°F	<12,000 S.U.S.
API Gravity	31.0/33.0
Flash, C.O.C.°F	400
Pour Point, °F	-25
Aniline Point, °F	210/220
Paraffinic Base Colour	Blue

### **Manifolds**

Description		Model Number	Dimensions (mm)
178 mm Long Manifold with 7 female ports		A-64	3/8"- 76 50 3/8"- 203 83 18NPTF (7x) 6,3 89 184
<b>369 mm Long Manifold</b> that allows direct mounting of control valves to the manifold. Plugs .38 NPTF.	1 m	A-65	32 32 32 32 102 102 102 32 369 A-64 A-65
6-Port Hexagon Manifold. Plugs furnished for all ports <sup>3</sup> / <sub>8</sub> "-18 NPTF.		A-66	58 21 50 50 1/4"-20UNC 3/8"-18NPTF (6x)
Premounted Manifolds	1 100	AM-21	Ø7.1 63 07.1 0 0
Split-flow valve to control two or four single-acting cylinders simultaneously.  AM-21 with 5 ports <sup>3</sup> / <sub>8</sub> " NPTF.  AM-41 with 7 ports <sup>3</sup> / <sub>8</sub> " NPTF.		AM-41	12,7 8 12,7 12,

# Hydraulic Oil, Manifolds and Fittings

#### **Recommended Tubing**

Enerpac does not supply high-pressure pipe or tubing, but recommends the use of cold drawn steel tubing in stead of regular pipe in the following dimensions:

In stead of .25" pipe, use 13 mm O.D. x 11 ga. (3 mm) wall.

In stead of .38" pipe, use 9 mm Schedule 80 seamless pipe.

In steadof .50" pipe, use 21 mm O.D. x .4 mm wall.

This tubing can be threaded with standard pipe threading dies.

A, AM BFZ FZ HF Series



						Series		and the same of th
Fitting	s 700 bar		Model Number	Dime	ensions (mm)			
Street Elbo	)W			Α	В	С	D	R
	-NPTF Male -NPTF Female		FZ-1616	23	33	<sup>3</sup> /8"-18 NPTF	<sup>3</sup> /8"-18 NPTF	D
Reducing (	Connector		FZ-1615	28	25	3/8"-18 NPTF	1/4"-18 NPTF	
From: 3/8"-	-NPTF Female	504	12 1010		20	75 1011111	74 10141 11	A
	-NPTF Female	4850						C. D.
	-NPTF Female	All halls	FZ-1625	47	29	<sup>1</sup> / <sub>2</sub> "-14 NPTF	<sup>3</sup> /8"-18 NPTF	B.
	-NPTF Female	1000						
Hexagon N	1							Α
From: 1/4"-NPTF	To: 1/4"-NPTF	5	F7 1/00	38	16	1/4"-18 NPTF	1/4"-18 NPTF	
3/8"-NPTF	3/8"-NPTF		FZ-1608 FZ-1619	51	19	3/8"-18 NPTF	3/8"-18 NPTF	CDD
3/8"-NPTF	3/8"-NPTF	-	FZ-1617	37	19	<sup>3</sup> /8"-18 NPTF	3/8"-18 NPTF	' <u>в</u> у '
Coupling	78 -INPTF		FZ-101/	31	1 7	/8 - 10 INF IF	70 - 10 INF 11	^
From:	To:	700						A
3/8"-NPTF	3/8"-NPTF		FZ-1614	29	23	<sup>3</sup> /8"-18 NPTF	<sup>3</sup> /8"-18 NPTF	C D
1/4"-NPTF	1/4"-NPTF	ACCESS:	FZ-1605	29	19	1/4"-18 NPTF	1/4"-18 NPTF	B/
Cross	74 101 11						,, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	
	-NPTF Female		FZ-1613	45	25	<sup>3</sup> /8"-18NPTF	_	
	-NPTF Female	THE STATE OF THE S						В
		45						A
Tee		-37-743						
From:	To:							
³/8"-NPTF	³/8"-NPTF	(Amy)	FZ-1612	45	25	3/8"-18 NPTF	-	B
1/4"-NPTF	1/4"-NPTF	ALC: U	FZ-1637	45	24	<sup>1</sup> / <sub>4</sub> "-18 NPTF	-	^
<sup>3</sup> / <sub>8</sub> "-NPTF	3/8"-NPTF	1	BFZ-16312	57	<sup>3</sup> /8"-18 NPTF	<sup>3</sup> /8"-18 NPTF	-	A A
Elbow		0						A
From:	To:	S THE STATE OF THE						
³/8"-NPTF	3/8"-NPTF		FZ-1610	33	20	<sup>3</sup> /8"-18 NPTF	-	Б В
¹/4"-NPTF	<sup>1</sup> / <sub>4</sub> "-NPTF		FZ-1638	36	24	1/4"-18 NPTF	-	C
Reducer								Δ
From:	То:	-						
3/8"-NPTF	1/4"-NPTF	AMA	FZ-1630	19	19	1/4"-18 NPTF	3/8"-18 NPTF	C D
1/4"-NPTF	1/2"-NPTF		BFZ-1630	28	22	1/4"-18 NPTF		B
3/8"-NPTF	G <sup>1</sup> / <sub>4</sub> "		BFZ-16301	19	19	G 1/4"	<sup>3</sup> /8"-18 NPTF	
Adaptor From:	То:							
G <sup>1</sup> / <sub>4</sub> "	10: 1/4"-NPTF	1	BFZ-16411	35	19	1/." 10 NIDTE	G <sup>1</sup> / <sub>4</sub> "	, A
G 1/4"	1/8"-NPTF	The state of the s	BFZ-16421	31	19	<sup>1</sup> / <sub>4</sub> "-18 NPTF <sup>1</sup> / <sub>8</sub> "-27 NPTF	G 1/4"	CDD
G <sup>3</sup> /8"	1/4"-NPTF		BFZ-16323	43	24	1/4"-18 NPTF	G <sup>3</sup> / <sub>8</sub> "	B/
G <sup>3</sup> /8"	3/8"-NPTF		BFZ-16324	43	24	3/8"-18 NPTF	G <sup>3</sup> /8"	2/
Adaptor	1 70 .41 11					75 .5141.11	2 70	
From:	То:							Α
1/4"-NPTF	³/8″-NPTF	15	FZ-1055	44	23	1/4"-18 NPTF	<sup>3</sup> /8"-18 NPTF	
¹/₄″-NPTF	¹/s"-NPTF		FZ-1642	30	19	1/8"-27 NPTF	1/4"-18 NPTF	C
¹/2″-NPTF	³/8"-NPTF		FZ-1634	42	28	<sup>3</sup> /8"-18 NPTF	1/2"-14 NPTF	B

www.enerpac.com ENERPAC. 2 129